

# Dice Chest - Small Assembly Instructions




## Important info and symbols.

You will need a sharp, narrow blade such as a utility or a hobby knife and some wood glue.

Some parts of the assembly has to be able to move. Be careful to not get glue into those areas, and allow glue to dry on parts before sliding them into place.

Parts are named sheet first, part second. Ex. 2.5 means sheet two, part 5. Parts that are the same, have the same number.

NB!!! Please do not print out these instructions unless absolutely necessary.




Cutting required




Glue required



Do not glue




Turn horizontally




Turn vertically




Warning: Choking hazard. Kit contains small parts.  
Not suitable for children under 3 years old.






x2

1




x4

2



x1

3




x4




4


















1



2







Do not glue into the round holes.  
It should spin freely.

